







W012638
Wire feed sensor

W013894
Wire feeder sensor control unit



W015290
Control cable wire feed sensor






userdoc.kemppi.com

Mounting instructions

W026640 R00

Monteringsvejledninger – Montageanleitungen – Instrucciones de montaje – Asennusohje –
Instructions de montage – Upute za montažu – Istruzioni di montaggio – Bevestigingsinstructies –
Monteringsinstruksjoner – Instrukcja montażu – Adisionais de montagem – Instrucțiuni de montare –
Инструкции по монтажу – Monteringsanvisning – Montaj talimatları – 安装指导





userdoc.kemppi.com

Mounting instructions

W026640 R00

Monteringsvejledninger – Montageanleitungen – Instrucciones de montaje – Asennusohje –
Instructions de montage – Upute za montažu – Istruzioni di montaggio – Bevestigingsinstructies –
Monteringsinstruksjoner – Instrukcja montażu – Adisionais de montagem – Instrucțiuni de montare –
Инструкции по монтажу – Monteringsanvisning – Montaj talimatları – 安装指导

